

# Assembly & Instruction Manual



# AC TRUCK APPLIANCES

## Model 3107



**Distributed Exclusively By**



**CUMMINS  
INDUSTRIAL TOOLS**



**THANK YOU FOR BUYING CUMMINS INDUSTRIAL TOOLS**

Your new Ac Truck Appliance has been engineered and manufactured to Cummins tools high standards for dependability, ease of operation, and operator safety.

**CAUTION:** Carefully read through this entire operator's manual before using your new machine

Pay close attention to the Rules for Safe Operation, Warnings, and Cautions. If you use your machine properly and only for what it is intended, you will enjoy years of reliable service.

**SAVE THIS MANUAL FOR FUTURE REFERENCE**



### **WARNING**

To reduce risk of injury, everyone using, installing, repairing, maintaining, changing accessories on, or working near this tool must read and understand these instructions before performing any such task.

Customer Service Postal Address:  
1290 35 Road  
Minden, NE 68959  
voice: 1-(308) 832-2070  
fax: 1-(308) 832-2069

*You can purchase additional  
items at [www.cumminstools.com](http://www.cumminstools.com)*

## Safety Warnings and Precautions

**WARNING: When using tool, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.**

**Read all instructions before using this tool!**

1. **Keep work area clean.** Cluttered areas invite injuries.
2. **Observe work area conditions.** Do not use machines or power tools in damp or wet locations. Don't expose to rain. Keep work area well lighted.
3. **Keep children away.** Children must never be allowed in the work area. Do not let them handle machines, tools, or extension cords.
4. **Store idle equipment.** When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep out of reach of children.
5. **Use the right tool for the job.** Do not attempt to force a small tool or attachment to do the work of a larger industrial tool. There are certain applications for which this tool was designed. It will do the job better and more safely at the rate for which it was intended. Do not modify this tool and do not use this tool for a purpose for which it was not intended.
6. **Dress properly.** Do not wear loose clothing or jewelry as they can be caught in moving parts. Protective, electrically non-conductive clothes and non-skid footwear are recommended when working. Wear restrictive hair covering to contain long hair.
7. **Use eye protection.** Always wear ANSI approved impact safety glasses underneath a full face shield during use. Also, wear heavy duty work gloves.
8. **Do not overreach.** Keep proper footing and balance at all times. Do not reach over or across running machines.
9. **Maintain tools with care.** Keep tools sharp and clean for better and safer performance. Follow instructions for lubricating and changing accessories. The handles must be kept clean, dry, and free from oil and grease at all times.
10. **Remove adjusting keys and wrenches.** Check that keys and adjusting wrenches are removed from the tool or machine work surface before starting work.
11. **Stay alert.** Watch what you are doing, use common sense. Do not operate any tool when you are tired.
12. **Check for damaged parts.** Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Any part that is damaged should be replaced.
13. **Replacement parts and accessories.** When servicing, use only identical replacement parts. Use of any other parts will void the warranty. Only use accessories intended for use with this tool. Approved accessories are available from Cummins Industrial Tools.
14. **Do not operate tool if under the influence of alcohol or drugs.** Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the tool.

**Warning: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.**

- 1: Lock Bar Grip
- 2: Lock Bar
- 3: Nut M6
- 4: Screw M6x17
- 5: Support Tube
- 6: Metal Plate
- 7: Screw M6x17
- 8: Nut
- 9: Washer
- 10: Converyer Belt
- 11: Axle
- 12: Binding Belt 1
- 13: Binding Belt 2
- 14: Frame
- 15: Anchor Plate
- 16: Pin
- 17: Spring Washer 10
- 18: Washer 10
- 19: Bolt M10x35
- 20: Wheel
- 21: Pin
- 22: Toe Plate
- 23: Nut M10

